



INSTRUCTIONS FOR LOW PROFILE SIGN/POST INSTALLATION

- 1) Place sign upside down with face protected on a flat surface.
- 2) Attach posts/pedestal to sign with supplied screws or drive rivets.
- 3) Using posts for alignment purposes mark position of holes on ground.
- 4) Using post hole digger, dig appropriate size holes to accommodate posts.
- 5) Standard height above ground is normally 28-32 in. For low-profile frames, with 32 in. being most common. May vary depending on your individual circumstances.
- 6) Pour a bag of ready-mix concrete into the hole of each post while leveling the frame/post and add water. (may pre-mix concrete and water if desired)
- 7) Replace additional fill into remaining hole around post making sure to keep sign frame plumb and level.